



www.tracitouch.com

(937)346-4420

Winholt Heated Cabinets

- The Heater-Proofing is an aluminum transport cabinet with heaters to function as a hot food holding cabinet, and/or as a proofing cabinet.
- The internal air circulation blower and 900w heater element (controlled with the "Heat" Thermostat) will operate continuously when the power switch is turned "ON".
- Allow **45 minutes for pre-heating**.
- To maintain low heat range between 85°F to 100°F, switch to proof mode and adjust heat knob to desired heat range.
- Be sure to disconnect power source before cleaning.

1. Push main power switch (ON/ OFF rocker) to "ON" position
2. Push HEAT/ PROOF switch to HEAT for heating ONLY
3. Turn HEAT thermostat knob fully clockwise for preheat
4. Allow 45 minutes for pre-heating, then turn thermostat to desired setting.
5. Place water in the "water pan" filling to about $\frac{3}{4}$ full, for proofing
6. For proofing, push HEAT/PROOF switch to PROOF.
7. Adjust the heat and humidity thermostat knob to control desired temperature and humidity.

HEAT THERMOSTAT

The controlling range is 80°F to 185°F. The dial has numbers 1 thru 9 that do not relate to a specific calibrated temperature. The dial also has an "OFF" position to turn heater unit off.

HUMIDITY THERMOSTAT

To control humidity range from 30% to 100%, humidity settings must be obtained through familiarization with the unit. The dial has numbers 1 thru 9 that do not relate to a specific calibrated humidity. The dial also has a "OFF" position to turn humidity off.

Reminder to the renter, you are responsible for the equipment from the time of receipt to the time of return. Please make sure equipment is secured and protected when not in use. A replacement charge will be assessed for all items missing.